


05 - Wi-Fi Setup

The dimmer code uses the Wifi autoconnect library

at the 1st firmware upload, it will create a "dimmer" wifi

once the user is connected to this Wifi, the browser will redirect to the page <http://192.168.4.1>

to ask you to configure your Wifi



Sign in to network
192.168.4.1

<u>MEO-WiFi</u>		100%
<u>MEO-620B4B</u>	🔒	94%
<u>MEO-AB4E8B</u>	🔒	16%

save

[Scan](#)

it will memorize your Wi-Fi connection confirmations even after a firmware update.

For more details: <https://www.raspberryme.com/wifimanager-avec-esp8266-connexion-automatique-parametre-personnalise-et-gestion-de-votre-ssid-et-mot-de-passe/>

Revision #2

Created 11 June 2022 15:44:35 by Cyril

Updated 11 June 2022 15:45:20 by Cyril